

LOMO'INSTANT 露出ガイド

									
天気	晴れ			薄曇り			曇り/日陰		
モード	(A)	(C)	(C)	(A)	(C)	(C)	(A)	(C)	(C)
フラッシュ	⚡	⚡	⊗	⚡	⚡	⊗	⚡	⚡	⊗
明るさ	A		-2	A	-1		A		A
シャッター スピード	N	N	N	N	N	N	N	N	N
									
天気	暗い曇り			曇天			夜/室内		
モード	(A)	(C)	(C)	(A)	(C)	(C)	(A)	(C)	(C)
フラッシュ	⚡	⚡	⊗	⚡	⚡	⊗	⚡	⚡	⊗
明るさ		+1		+1		---	A	A	---
シャッター スピード	N	N	N	N	N		N	N	